




Right Connections

towbar wiring kits for the uk


FIAT/ JEEP

500X 05/2015 >>
Renegade 02/2015 >>
Renegade Hybrid 08/2020 >>

Part No: FI-048-07M

Electric wiring kit for towbars / 7-pin / 12N / 12 Volt / ISO 1724

Fitting instructions



IMPORTANT!

This electric kit has to be installed by a professional workshop or a suitable qualified person.

The installation instructions must have been read and fully understood before the start of any installation. Please contact your wiring kit provider or the hotline shown in the footer should you need assistance!

Make sure the vehicle is approved/homologated by the manufacturer to tow a trailer!

Also please check that there is a definite compatibility between this vehicle and the electric kit!

Following the installation of the electric kit, the fitting instructions should be kept together with the vehicle service document and vehicle handbook. The fitting instructions contain important information relating to the use and function of the towing kit as well as for any diagnostic or activation process, that might have to be repeated in the future (e.g. after the performance of a vehicle software update).

All warranty claims will be forfeited if the electric kit or components contained therein are used incorrectly or modified. If a towing socket adaptor has been used to connect to the trailer or bike rack, this must be removed from the trailer socket once the trailer or bike rack has been disconnected.

If the trailer or bike rack is not equipped with a rear fog lamp, depending on the towing vehicle type, the correct function of the towing kit cannot be guaranteed. In such cases, a rear fog lamp should be retro fitted.

This towing electric kit will not be covered under warranty if any technical or electrical modifications or software updates have been performed by the vehicle manufacturer after the initial commissioning of the kit. That applies especially to modifications or updates which may cause malfunctions in the trailer socket or any other part of the trailer electrical equipment!

Depending on the type of trailer module used in this electric kit, diagnostic interrogation with the vehicle's electrical system may be limited or will not function. The error memory inside the trailer module may not be able to be accessed by vehicle manufacturers diagnostic system.

Error logs relating to the trailer electrical equipment, that may be generated in the vehicle manufacturers diagnostic system as a result of a test procedure, may be due to the incorrect installation of the towing electric kit or the false activation of the trailer module.

We always recommend whenever possible, the following troubleshooting process:

→ **An analysis of the vehicle's error memory and possibly clearing of all faults before the start of the installation!**

→ **Try disconnecting the trailer module from the towing harness and re-start the fault clearing process!**

→ **If in doubt, limit the time for troubleshooting to a max of 0,5 hours and call our Technical Support Team!**

Please follow our instructions carefully and always test the towing electrics using a true lighting board or a specifically designed bulb tester. If an LED tester is used, ensure it is equipped with correct load resistors or malfunctions will occur!

This instruction is subject to changes and we reserve the right to make changes to design, colour etc.

All of the data and illustrations may not be an exact representation but the text contained in this instruction must be observed!



M

G I

M1

5x

L2

L1

X

A

B1





F

R

D

E

C



3x

3x

3x

1x

20 Amp.
minifuse

1x

10x

1x

4x

2x


1x

1x

B

1x

FIAT 500X / JEEP Renegade





SYMBOL EXPLANATION

	Left (58-L) respectively Right (58-R) tail light
54	Stop light (54) / high mounted, third stop light (54)
	Turn signal indicator left
	Turn signal indicator right
	Rear fog light(s)
	Reversing light(s)
	Permanent power supply / 13pin socket, chamber 9
	Charging wire for trailer battery / 13pin socket, chamber 10
	Trailer / trailer recognition
B+ / 30	Permanent current power supply
	Ground or Earth (31)
	Ground connection battery terminal lug
	Positive connection battery terminal lug


	Cigarette lighter / accessory socket
	Loudspeaker / buzzer
	Park Distance Control
	Switch / source of function
	Connect together
	Disconnect
	Look at / See further information
	Look carefully at selected area
	Present / Occupied / OK
	Not present / Not occupied / Not OK
	Acoustic indication
	Attention / important advice
	Fuse / fuse capacity 20 Ampère

TOOLS



ATTENTION!

The vehicle's cooling capacity may have to be increased when retrofitting a trailer coupling!
You must observe the manufacturer's instructions!!



Note: It may be necessary to check if this vehicle has a stored radio code before disconnecting the battery!



ATTENTION!


In order to avoid mal-functions and damage to the vehicle's electrical system the earth terminal **must be disconnected** from the vehicle's battery **before starting work!**

Both the trailer module and the vehicle's control unit for the electrical system can be damaged during work on the data bus connections if the battery is not disconnected!


Please pay attention to the manufacturer's instructions when disconnecting and reconnecting the vehicle's battery!

1


500X




500X



500X




Renegade




5

Renegade




6

Renegade




7

500X / Renegade








8

Jeep Renegade




Fiat 500 X




9


Option 1



Option 2



10




11

SOCKET CONNECTION



DIN/ISO 1724	← L	⊕	⊥ 1-7	R →	☀	STOP	☀
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	21W		21W	42W	3x21W	42W
	Yellow	Blue	White	Green	Brown	Red	Black

12



13


Option 1




14

Option 2


1




2



3




4




15

Option 2


1




2



3




4




16


1





2




3




4




5




6




7



8





9





17

500X





18


Renegade






19




20





21





22



Renegade




23





Renegade

cut to length !!




24

Renegade



25








Vehicles with PDC-System





Vehicles without PDC-System




26




27




1




2





3



4





Renegade




29

Renegade




1




2

30



500X / Renegade



31





32



33


CAN bus connection



BCM
(Body control Module)

SGW
(Security Gate Way)

SGW Security Gate Way



**8-pole
Black**

34

SGW
not fitted



35

37

47

→

SGW
fitted




36



47

→

Without Security Gate Way



OBD




CAN-Data Wire



PIN3

PIN11



CAN High


Pin 3
Blue or Grey

CAN Low

Pin 11
White



Important!
Please note
informations in
picture 1!




Black → OBD
PIN 3

Yellow → OBD
PIN 11

Black
Yellow


35

With Security Gate Way



Important!
Please note
informations in
picture 1!

SGW Security Gate Way



CAN-Data Wire



PIN3
PIN8





CAN High








Pin 3
Blue or Purple/White

CAN Low

Pin 8
White or Yellow/Blue

8-pole
Black






Important!
Please do not mount the fuse tap
and its wiring output in the other
direction!

Optional


Reverse



MAX = 21W




40



12S socket

41




Optional





**Right
Connections**
towbar wiring kits for the uk

42






Trailer Simulator for 7- and
13-pin Sockets

Functional test



43








44

Optional


Adapter socket



45



46



47